Blitz Cold Spark Safety Suggestions

Warnings and Cautions

These are designed to alert your attention to important information that assists you in carrying out your activities with the ProX Blitz Cold Spark machine safely and efficiently.



WARNING: A WARNING ALERTS YOU TO HARMFUL OR POTENTIALLY DANGEROUS ACTIVITIES. A DESCRIPTION OF THE HAZARD IS GIVEN AND THE CONSEQUENCES OF IGNORING THEM.

PLEASE NOTE THAT THE PROX BLITZ UNITS ARE NOT MEANT TO BE A CONTINUOUS DURATION EFFECT. THE MAXIMUM RUNNING TIME IS 60-90 SECONDS AND CAN BE REPEATED BUT SHOULD NOT BE DONE TOO RAPIDLY TO NOT ALLOW COOLING TIME BETWEEN BURSTS!



Eye Protection

THE EYE PROTECTION WARNING ICON IS SHOWN TO INDICATE THAT YOU MUST BE PROTECT YOUR EYES WHEN CLOSE TO THE MACHINE DURING MACHINE OPERATION.

Injury Voltages

WARNING: DANGEROUS VOLTAGES ARE PRESENT IN THIS MACHINE AND CONTROLLER WHEN ELECTRICAL POWER IS APPLIED. THERE IS A DANGER OF INJURY FROM ELECTRIC SHOCK.



UNDER NO CIRCUMSTANCES ARE YOU TO ATTEMPT TO OPEN THE MACHINE AND CONTROLLER OR ATTMPT TO REMOVE OR ADJUST ANY COMPONENTS FITTED WITHIN THE MACHINE AND CONTROLLER. ONLY FULLY TRAINED PROX SERVICE ENGINEERS ARE QUALIFIED TO OPEN THE MACHINE AND CONTROLLER.



Liquid Cautions

WARNING: USE CAUTION SO THAT ANY LIQUIDS DO NOT WET THE MACHINE. KEEP THE MACHINE AND CONTROLLERS DRY AND DO NOT USE ON RAINY OR SNOWY DAYS UNLESS COVERED. DO NOT COVER FOUNTAIN PORT DURING OPERATION!

Warning

PLEASE PREVENT ANYTHING FROM ENTERING THE FOUNTAIN DISCHARGE PORT. IF THIS HAPPENS PLEASE CLEAR OBSTRUCTIONS BEFORE CONTINUING OPERATION. DO NOT DROP THE MACHINES, SERIOUS DAMAGE CAN OCCUR.

Granules



IF THE BAGGED GRANULES ARE INVOLVED IN A FIRE THE SUGGESTED METHOD OF EXTINGUISHING IS BY SAND OR DRY CHEMICAL EXTINGUISHER. DO NOT TRY TO EMPTY THE MACHINE AS THIS WILL RESULT IN EXPOSING THE GRANULES. USE ONLY THE GRANULES FROM PROX DESIGNED FOR THE

BLITZ MACHINES. USE OF OTHER SIMILAR GRANULES WILL VOID THE WARRANTY.

Safe Distance

KEEP AUDIENCE AND FLAMMABLE MATERIALS AT A MINIMUM SAFETY DISTANCE OF 10 FEET. KEEP OUT OF REACH OF THE PUBLIC! MAINTAIN A 3 FOOT EXCLUSION ZONE AROUND EACH MACHINE WITH NOTHING BUT THE POWER AND CONTROL CABLES IN THIS AREA!

In Case of Emergency



IF THE MACHINE NEEDS TO BE STOPPED QUICKLY DUE TO AN EMERGENCY, PRESS THE "PAUSE" / "STOP" KEY ON THE CONTROLLER TO STOP THE MACHINE AND TURN THE POWER SWITCH ON THE PANEL OF THE MACHINE TO THE "OFF" POSITION.

CALL FOR MEDICAL ASSISTANCE AS REQUIRED.

Noise Emissions



THE NOISE EMISSION LEVEL FROM THIS MACHINE DOES NOT EXCEED 80 DB. THERE IS NO HAZARD TO HEARING AND, THEREFORE, NO LEGAL REQUIREMENT FOR EAR PROTECTION TO BE WORN WHEN WORKING IN THE VICINITY OF THIS MACHINE.

Cleaning



PLEASE INSPECT FOUNTAIN NOZZEL OF THE BLITZ MACHINE BEFORE USE AND CONFIRM THERE ARE NO ACCUMULATED GRANULES. PLEASE CLEAN OUT ANY EXCESS BY INVERTING THE UNIT TO CLEAN OUT PORT. THIS SHOULD BE DONE EACH TIME BEFORE THE MACHINE IS SETUP AND BE PERFORMED BEFORE RETURING THE UNITS TO THEIR ROAD CASE. THIS WILL HELP TO PROLONG THE PUTT MACHINE. THE FOUNTAIN PORT CAN BE CLEANED WITH A POTTLE PRUSH AS

THE LIFE OF THE BLITZ MACHINE. THE FOUNTAIN PORT CAN BE CLEANED WITH A BOTTLE BRUSH AS NECESSARY

Power Supply Requirement



POWER REQUIREDMENTS ARE 115VAC 3AMPS EACH. **PLEASE NOTE:** ONE STANDARD CIRCUIT CAN SUPPORT A MAXIMUM OF 6 PROX BLITZ MACHINES. EACH MACHINE CAN BE CONNECTED INDIVIDUALLY OR DAISY CHAINED WITH POWER-CON SERIES CABLES